

Download How To Turn Off Dnd On Nec Phone

How do you remove the DND feature on phone model NEC Dterm Series III? Please help. My extension on the phone gives busy signal to all calls with DND showing on the phone. While on-hook, press DND. Select the DND type. Off = Turn DND off. Alternately dial 0. External (Ext) = Block incoming outside calls. If that doesn't work, you need to make sure DND is PROVIDED for this phone. Most likely if you can't turn it off, NOT PROVIDED is selected. Most likely if you can't turn it off, NOT PROVIDED is selected. NEC Business Phone System – How to Set and Cancel Do Not Disturb (DND) NOTE: The instructions below apply to NEC DT800 IP Phones and NEC DT400 Digital Phones on the NEC SV9100 telephone system with InMail as well as NEC DT700 IP Phones and NEC DT300 Digital Phones on the NEC SV8100 Phone System.